




DHOLLANDIA

DH-VO, VB, VX multi-deck tail lifts

OPERATION MANUAL



Manufacturer:
DHOLLANDIA N.V. Zoomstraat 9 9160 LOKEREN (Belgium)
Tel : +32 (0)9 349 06 92 Fax : +32 (0)9 349 09 77
e-mail : info@dhollandia.be
website : www.dhollandia.com

Read the manual in its entirety before operating the liftgate

Keep this manual in the vehicle cab, as reference for the driver and liftgate operator

TABLE OF CONTENTS

1	UNDERSTANDING SAFETY AND WARNING SIGNS.....	2
2	CONTACT INFORMATION AND DISCLAIMERS.....	3
3	GENERAL INTRODUCTION	4
4	INTENDED USE	4
5	IDENTIFICATION	5
6	DESCRIPTION AND TAIL LIFT TERMINOLOGY.....	6
6.1	General	6
6.2	Safety devices.....	18
7	SAFETY INSTRUCTIONS FOR USING THE TAIL LIFT	22
7.1	DO NOT use tail lift without adequate safety and operator training	22
7.2	General safety instructions.....	22
7.3	Danger zones, risk of crush and shear injury	26
7.4	Additional risks of lifting above the vehicle floor level.....	29
7.4.1	Risk of falling	29
7.4.2	Risk of other persons standing under the platform	30
7.4.3	Risk of crushing and shearing.....	31
7.4.4	At the vehicle roof.....	33
7.4.5	Special attention for overhead cross tube between the lift runners	33
7.5	Safe operator position	34
7.6	Instructions for working at loading docks	37
7.7	Recommended daily pre-trip inspection	40
7.8	Importance of preventative maintenance	42
8	LOAD CHARTS AND CORRECT LOADING PROCEDURES.....	43
9	OPERATING INSTRUCTIONS – PRINCIPLES AND PROCEDURES	46
9.1	Platform ride.....	46
9.2	Main external control boxes	47
9.3	Auxiliary controls.....	50
9.4	Switching the main power ON / OFF	52
9.5	Operation of the standard multi-deck column lift with hydraulic closure.....	53
9.6	Operation of the internal column lift without tilt cylinders.....	56
9.7	Operation of the DH-VO.20.D4 removal lift	59
9.8	The use of stabilizing legs	64
9.9	The use of cart stops.....	65
10	DECALS.....	68
11	MEANING OF SAFETY AND WARNING SIGNS	72
12	END NOTE	74

1 UNDERSTANDING SAFETY AND WARNING SIGNS

Many safety signs and symbols used in this manual are based on international standards, others refer to specific situations or actions.

Consult section 11 **Error! Reference source not found.** page 72 **Error! Bookmark not defined.** for an overview of signs and symbols used in DHOLLANDIA manuals and their meanings.

Please take special notice of the following signs used in the manual. They indicate the likelihood and severity of a potential injury if a person fails to follow the instructions presented on the safety sign.



DANGER: indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. [white letters on red background]



WARNING: indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. [black letters on orange background]



CAUTION: indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury. [black letters on yellow background]



NOTICE: is used to address practices not related to physical injury. [white letters on blue background]



SAFETY INSTRUCTIONS: indicate general instructions relative to safe work practices, reminders of proper safety procedures, or the location of safety equipment. [white letters on green background]



SAFETY ALERT SYMBOL: is used to alert the user to potential hazards. All safety messages that accompany this sign shall be obeyed to avoid possible harm. [free-standing, or on background colours red, orange, yellow or black]



- Failure to understand and follow the instructions in this manual can put the operator and any bystanders at great risk of serious bodily injury and death.
- Prior to operating the tail lift, make sure you understand the safety and warning signs used, and read them in conjunction with the instructions in this manual.
- If in doubt, DO NOT operate the tail lift. Contact your national DHOLLANDIA distributor. See page 3 for contact info.

2 CONTACT INFORMATION AND DISCLAIMERS

- DHOLLANDIA liftgates are regularly being adapted to new vehicle and chassis developments and specialized customer requirements. Therefore, DHOLLANDIA reserves the right to alter product specifications without prior notice; and potentially modifications or new developments might not have been taken into account at the time of printing.

NOTICE

Please confirm you have reviewed the most up-to-date version of this manual prior to operation of the associated DHOLLANDIA liftgate. See below for instructions to download the latest version of the manual.

- Contact your national DHOLLANDIA distributor if you have any questions regarding the installation, operation, repair and maintenance of DHOLLANDIA liftgates, to obtain replacement copies of manuals or decals, or to learn about available equipment options for DHOLLANDIA liftgates.



If in doubt where to find your national DHOLLANDIA distributor, visit the official DHOLLANDIA website
www.dhollandia.com → **Country selection / language selection** → **Distributors & service**



The latest version of all manuals can also be downloaded from the DHOLLANDIA website
www.dhollandia.com → **Downloads** → **User's manuals** → ... **select required manual**

- Take notice of following important disclaimers:

DISCLAIMERS

- DHOLLANDIA disclaims liability for any personal injury, death, or property damage that results from **operating a liftgate that has been modified from the original design**, without explicit written approval from the manufacturer.
- DHOLLANDIA disclaims liability for any personal injury, death, or property damage that results from **use of aftermarket or non-OEM replacement parts for service or repair of the liftgate**.
- DHOLLANDIA disclaims liability for any personal injury, death, or property damage that results from **improper use of the liftgate**.
- DHOLLANDIA disclaims liability for any personal injury, death, or property damage that results from **overloading or improperly loading the platform**, disregard of the maximum rated lift capacity and the applicable load charts.
- There are no warranties, express or implied, including the warranty of merchantability or a warranty of fitness for a particular purpose extending beyond that set forth in this manual.

3 GENERAL INTRODUCTION

- This OPERATION MANUAL explains how the DHOLLANDIA liftgate is manufactured, what safety devices are incorporated in its design; and how to use the liftgate in a correct manner, that preserves the integrity of the machine over the intended lifetime and helps maximize the safety of the operator and any bystanders.
- The MAINTENANCE AND REPAIR MANUAL (separate) explains how to maintain and service the liftgate in the appropriate manner, maximizing the safety of the operator and any bystanders, and ensuring the reliability of the liftgate over the intended lifetime.
- The CE IDENTIFICATION AND INSPECTION BOOK (separate) contains the serial number identification, the CE Declaration of Conformity, the Fitting Declaration to be filled out by the installer of the tail lift, and an overview of the owner's legal obligations in terms of periodic testing and certification.
- The manuals must be kept with the liftgate at all times, as a reference book for the operators and technical service



WARNING

- Improper use of the liftgate will put the operator and other parties at great risk of serious bodily injury and death. Therefore, the use of the liftgate is restricted to skilled operators only; who have been properly trained, and who know and understand the full contents of this manual.
- Unauthorized modifications to the liftgate can put the operator and other parties at great risk of serious bodily injury and death. Therefore, it is strictly forbidden to modify the liftgate and its safety devices in any way.
- Use of aftermarket or non-OEM replacement parts to repair or maintain the liftgate is strictly prohibited and may result in serious bodily injury or death to the operator or any bystanders.

4 INTENDED USE

DHOLLANDIA liftgates are designed to be fitted to commercial vehicles (commercial trucks, trailers and semi-trailers), and shall be used exclusively to load and unload the goods transported on the vehicle it is fitted to, within the limits of the load chart, in compliance with the operator instructions and safety instructions described in this manual.




WARNING


- Improper use of the liftgate will put the operator and bystanders at great risk of serious bodily injury and death. Therefore, it is strictly forbidden to use the liftgate in a different way, or for different purposes than described in the operation manual.
- The liftgate must NEVER be used as an elevated work platform, to push loads, or to carry people.
- The liftgate must NEVER be used as a wheelchair lift.
- DHOLLANDIA disclaims liability for any personal injury and / or property damage that results from improper use.

5 IDENTIFICATION

- Every DHOLLANDIA tail lift is identified by and labelled with a **unique 8-digit serial number** (with or without a space between the first and last 4 digits). Use this number for any inquiry on a particular tail lift, or when ordering replacement parts.
- In addition to the tail lift type and serial number, the various serial number labels provide additional information, such as: the maximum rated lift capacity and load chart, the bumper certification number, the date of manufacture, etc...
- These labels are usually affixed to the vehicle body and various tail lift components, and can be found in following locations (the yellow arrows point to the serial numbers):



Affixed to the side of the vehicle body, or on the



1



2



3





Image shows model DH-VO

6 DESCRIPTION AND TAIL LIFT TERMINOLOGY

6.1 GENERAL


- DHOLLANDIA tail lifts are developed and manufactured using state-of-the-art technology, high quality materials and components, and highly skilled workmanship. They comply with the European CE safety regulations mentioned in the Declaration of Conformity issued with each lift (unless agreed otherwise for tail lifts exported outside of CE region).
- The range of multi-deck column lifts DH-V* comprises of a wide variety of constructions with different lifting mechanisms, but share main components such as the platform and its safety features, cart-stop and ramp options, safety devices etc.
- These column lifts are designed for a wide variety of trucks, trailers and semi-trailers, and offer lift capacities of 750 to 4.000 kg.
- When considering the drive mechanism of the various lifts, the following types can be distinguished between:

Fig. nr	Type	Description
1	DH-VB*	Overhead beam lift: operated by a single lift cylinder mounted in a beam at the vehicle roof level and a set of steel ropes and pulleys
2	DH-VO*	Lower beam lift: operated by a single lift cylinder mounted in a beam at, or below the vehicle floor level and a set of steel ropes and pulleys, or heavy-duty chains and chain wheels
3	DH-VX*	Operated by a single lift cylinder mounted in vertically positioned cylinder beam integrated in the right side column, and a set of steel cables and pulleys
4	DH-VH*	Operated by 2 hydraulic lift cylinders mounted in the left and right side columns. No cables or chains involved.



- When considering where the platform operates, the following types can be distinguished between:

Fig. nr	Type	Description
5	External lift	<ul style="list-style-type: none"> • In its travel position, the platform is stowed vertically behind the vehicle body. Before use, the platform is lowered approx. 10 cm, then tilted open 90 degrees from the vertical travel position, to a horizontal work position. • The external lift has the 4 functions: OPEN - LOWER - LIFT - CLOSE • Usually the opening and closing of the platform is driven by 2 hydraulic tilt cylinders. But depending on options chose, manual closing or hydraulic closure by 1 hydraulic tilt cylinder (without adjustable platform orientation) are also available.
6	Internal lift	<ul style="list-style-type: none"> • Lifting platform or “moving deck” travelling UP - DOWN between 2 or more decks inside the vehicle body. • Usually the internal lift has no tilt cylinders, no adjustable platform orientation.



- Main details and terminology: see next pages

NOTICE

- The range of multi-deck column lifts DH-V* comprises of a wide variety of lifts with an even wider variety of options, which cannot all be covered within the scope of this generic operation manual.
- The images in the next pages are therefore only examples of popular execution, but might differ from the column lift actually delivered to you.
- Even if details in the execution of your lift are not reflected in this manual, the general safety precautions and operation instructions apply, and must be observed prior to and during operation.




WARNING


If in doubt on any tail lift related issue, ALWAYS contact your local DHOLLANDIA distributor for help or advice, prior to continuing.

See figure below for parts corresponding to the numbers in this table

#	Description
1	Lift columns L+R: set of 2 columns mounted in a fixed position against the vehicle body. They form the rails in which the lift runners carrying the platform travel up and down.
2	Cylinder beam: horizontal or vertical beam mounted at various positions. Check the difference between DH-VO, VB and VX above . This beam contains the lift cylinder, the drive system consisting of steel ropes and pulleys.
1+2	Lift frame: the lift columns + cylinder beam together form the lift frame.
3	Lift cylinder: usually 1 hydraulic cylinder used to LOWER / LIFT the lift runners, the platform and its load.
4	Drive system: set of steel ropes and pulleys, or chains and chain wheels, used to transfer the movement induced by the lift cylinder to the lift runners and the platform. The drive system usually contains multiple tiers, so that the stroke of the cylinder can result in a multiplied vertical travel of the lift runners and the platform.
5	Platform: carries the load during lifting and lowering. Usually manufactured from a steel frame with aluminium infill profiles with a non-slip working surface, although full aluminium or feel steel platforms are also available. In standard execution, the platform is equipped with a fixed leading edge. Optional cart-stops or a retention ramp at the outboard platform edge, are available as an option.
6	Lift runners L+R: set of 2 slides carrying the platform, travelling up and down in the lift columns. They are lifted and lowered by the lift cylinder and the drive system.
7	Stow lock L+R: set of hooks mounted on the left and right side of the platform, keeping it in its travel position while not being used, and pressing it against the sealing rubbers (if so equipped) to form the rear closure of the vehicle body.
8	Guard rails L+R: rails to protect the operator against falling from heights, and incurring serious personal injuries. They should be used on all exposed platform sides. The tail lift standard EN1756-1 makes them compulsory for all lifting heights above 2m.
9	Auxiliary controls: LIFT / LOWER controls integrated in one of the guard rails
10	Toe-guard flap: hinged flap + detection switch stopping the LIFT function when a person steps on it, or load stands on it. It aims at protecting the toes and feet of the operator in the dangerous crushing zone between the moving platform and the loading floors of the vehicle.
11	Tilt cylinders L+R: usually 2 hydraulic cylinders used on external lifts to OPEN / CLOSE the platform, or to change its angle when opened in work position. Depending on options chose, manual closing or hydraulic closure by 1 hydraulic tilt cylinder (without adjustable platform orientation) are also available.
12	Side shrouds and seals L+R: set of panels and sealing rubbers mounted on the left and right side columns of external lifts, used to seal the platform against the columns, and protect the cargo from rain. The shrouds can be original DHOLLANDIA parts, or be designed and manufactured by the body builder.
13	Hydraulic pump unit: contains the electric motor driving the hydraulic pump, the oil tank, and the control valves. The unit is mounted separately on the vehicle chassis.
14	Main external control box: mounted in a fixed position at the side of the vehicle or under the body. It contains the switches to OPEN - LOWER - LIFT - CLOSE the platform.

EXAMPL






See figure below for parts corresponding to the numbers in this table

#	Description
1	Lift columns L+R: set of 2 columns mounted in a fixed position against the vehicle body. They form the rails in which the lift runners carrying the platform travel up and down.
2a	Overhead cross member: cross member of the lift frame located just below the vehicle roof.
2b	Floor cross member: cross member of the lift frame located just below the vehicle roof level.
1+2	Lift frame: the lift columns + overhead and floor cross members together form the lift frame.
3	Lift cylinders L+R: 2 hydraulic cylinders mounted in the lift columns, used to LOWER / LIFT the lift runners, the platform and its load.
4	Platform: carries the load during lifting and lowering. Usually manufactured from a steel frame with aluminium infill profiles with a non-slip working surface. In standard execution, the platform is equipped with a fixed leading edge. Optional cart-stops or a retention ramp at the outboard platform edge, are available as an option.
5	Lift runners L+R: set of 2 slides carrying the platform, travelling up and down in the lift columns. They are lifted and lowered by the 2 lift cylinders mounted in the lift columns.
6	Stow lock L+R: set of hooks mounted on the left and right side of the platform, keeping it in its travel position while not being used, and pressing it against the sealing rubbers (if so equipped) to form the rear closure of the vehicle body.
7	Hydraulic retention ramp: optional full-width load restraint flap, operated by a hydraulic cylinder in the platform and the electric controls of the lift (9 or 13). When travelling up and down, the ramp can be raised in vertical position to prevent carts and wheeled objects from accidentally falling off the platform. At the ground, the ramp can be deployed as an access ramp to drive cargo on and off the platform.
8	Guard rails L+R: rails to protect the operator against falling from heights, and incurring serious personal injuries. They should be used on all exposed platform sides. The tail lift standard EN1756-1 makes them compulsory for all lifting heights above 2m.
9	Auxiliary controls: LIFT / LOWER controls integrated in one of the guard rails. If an optional hydraulic ramp is mounted (see n° 7), additional controls are mounted on the guard rails to RAMP UP / RAMP DOWN.
10	Side loading ramps: optional combination of guard rails and side loading ramps. In travel position, these ramps are folded down on the platform surface. When raised and blocked in vertical position, they function as guard rails (see n°8). When opened up to the side, they function as side ramp for loading or unloading cargo to the kerb.
<div style="background-color: #0000FF; color: white; padding: 5px; font-weight: bold; font-size: 1.2em;">NOTICE</div> <div style="border: 1px solid black; padding: 10px; margin-top: 5px;"> <p>Although the side loading ramps can be blocked in vertical position as guard rails for the operator on the platform, they are NOT designed to function as heavy-duty load-restraints and to sustain frequent, hard impact by means of carts or pallets run into them.</p> </div>	
11	Tilt cylinders L+R: usually 2 hydraulic cylinders used on external lifts to OPEN / CLOSE the platform, or to change its angle when opened in work position.
12	Hydraulic pump unit: contains the electric motor driving the hydraulic pump, the oil tank, and the control valves. The unit is mounted separately on the vehicle chassis.


13	Main external control box: mounted in a fixed position at the side of the vehicle or under the body. It contains the switches to OPEN - LOWER - LIFT - CLOSE the platform. In case an optional hydraulic retention ramp is mounted, the control box also incorporates the functions RAMP UP / RAMP DOWN.
----	---



DH-VH FULLY HYDRAULIC EXTERNAL COLUMN LIFT + INTERNAL PLATFORM • HYDRAULIC CLOSURE

See figure below for parts corresponding to the numbers in this table


#	Description
1	Lift columns L+R: set of 2 columns mounted in a fixed position against the vehicle body. They form the rails in which the lift runners carrying the platform travel up and down.
2a	Overhead cross member: cross member of the lift frame located just below the vehicle roof.
2b	Floor cross member: cross member of the lift frame located just below the vehicle roof level.
1+2	Lift frame: the lift columns + overhead and floor cross members together form the lift frame.
3	Lift cylinders L+R: 2 hydraulic cylinders mounted in the lift columns, used to LOWER / LIFT the lift runners, the platform and its load.
4a	External platform: raised and lowered by the L+R lift cylinders and carries the load during lifting and lowering. Usually manufactured from a steel frame with aluminium infill profiles with a non-slip working surface. In standard execution, the platform is equipped with a fixed leading edge. Optional cart-stops or a retention ramp at the outboard platform edge, are available as an option.
4b	Internal "slave" platform: internally mounted section of the platform that can also carry load during lifting and lowering. It is called "slave" platform, because it has no own lift system to travel up and down independently from the external platform: it can travel up / down when linked to the external platform, or stay parked at the upper or lower deck when disconnected from it. The locking device used to park the internal platform at the second deck is provided by the vehicle manufacturer.
5	Lift runners L+R: set of 2 slides carrying the platform, travelling up and down in the lift columns. They are lifted and lowered by the 2 lift cylinders mounted in the lift columns.
6	Stow lock L+R: often, rear swing doors behind the external platform are used to form the rear closure of vehicle body. Hence, depending on execution, this type of external platform might not be equipped with stow locks as shown in item 6 on previous page.
7	Hydraulic retention ramp: optional full-width load restraint flap, operated by a hydraulic cylinder in the platform and the electric controls of the lift (9 or 13). When travelling up and down, the ramp can be raised in vertical position to prevent carts and wheeled objects from accidentally falling off the platform. At the ground, the ramp can be deployed as an access ramp to drive cargo on and off the platform.
8	Guard rails L+R: rails to protect the operator against falling from heights, and incurring serious personal injuries. They should be used on all exposed platform sides. The tail lift standard EN1756-1 makes them compulsory for all lifting heights above 2m.
9	Auxiliary controls: LIFT / LOWER controls integrated in one of the guard rails. If an optional hydraulic ramp is mounted (see n° 7), additional controls are mounted on the guard rails to RAMP UP / RAMP DOWN.
10	Tilt cylinders L+R: usually 2 hydraulic cylinders used on external lifts to OPEN / CLOSE the platform, or to change its angle when opened in work position.
11	Hydraulic pump unit: contains the electric motor driving the hydraulic pump, the oil tank, and the control valves. The unit is mounted separately on the vehicle chassis.
12	Main external control box: mounted in a fixed position at the side of the vehicle or under the body. It contains the switches to OPEN - LOWER - LIFT - CLOSE the platform. In case an optional hydraulic retention ramp is mounted, the control box also incorporates the functions RAMP UP / RAMP DOWN.



LOAD RESTRAINTS • TAIL LIFT TERMINOLOGY

See figure below page for parts corresponding to numbers in this table

#	Description
1	Platform: carries the load during lifting and lowering. Manufactured from steel or light-weight aluminium and with a non-slip working surface. In standard execution, the platform is equipped with a fixed leading edge. Optional cart-stops in the platform surface, or a retention ramp at the outboard platform edge, are available as an option.
2	Cart-stops: usually 2 load restraint flaps mounted in or just in front of the fixed leading edge of the platform. Depending on options chosen, the cart-stops feature a manual or an automatic operation (see also §9.9 from page 65 onwards) and are actuated by springs.
3	Rear or outboard retention ramps : 1 full-width or 2 partial width load restraints ramps mounted at the outboard platform edge. In travel position, the ramps lie folded back on the platform surface. When travelling up and down, the ramps can be raised and blocked in vertical position to prevent rolling cargo on the platform from falling off. At the ground, the ramps can be deployed as an access ramp to drive cargo on and off the platform. (See also §9.9 from page 65 onwards).
4	Side retention ramps : 2 load restraints ramps mounted at the side edges of the platform. In travel position, the ramps lie folded back on the platform surface. When travelling up and down, the ramps can be raised and blocked in vertical position to prevent rolling cargo on the platform from falling off. At the ground, the ramps can be deployed as an access ramp to drive cargo on and off the platform. (See also §9.9 from page 65 onwards)
	See previous page for the optional hydraulic retention ramp (n° 7).




6.2 SAFETY DEVICES

DHOLLANDIA tail lifts are equipped with a multiple safety devices in order to ensure that goods can be loaded and unloaded with maximum safety for the operator, any incidental bystanders, and the load itself. The safety devices listed below are incorporated or recommended on most tail lifts.


Note: the illustrations below are examples for the most common types of lifts, and might differ from the actual devices on your lift. If any further information is required, please contact your national DHOLLANDIA distributor. See page 4 for contact info.

- **Electrical safety valves mounted on all cylinders** [standard]. The safety valves lock the oil inside the hydraulic cylinders as long as they are not energized via the electrical controls. The purpose is to secure the platform in its travel position while driving, or in any other fixed position, in case of accidental failure of a hydraulic pipe (as soon as the electrical controls are released).

DHOLLANDIA safety valves are equipped with a manual emergency control, allowing the operator or repair agent to open the valve manually in case of electrical failure (see MAINTENANCE AND REPAIR MANUAL).




Safety valve on tilt cylinder (DH-VO)



Safety valve on lift cylinder (DH-VO)

- **Mechanical platform lock(s)** [optional]. DHOLLANDIA offers (a) mechanical platform lock(s) as an option, to further secure the platform in its travel position in case of accidental loss of hydraulic pressure.


The use of a platform lock is good and safe practice in general. Also, depending on the vehicle pay-load and the type of tail lift, extra locks might be compulsory to comply with the CE load containment regulations EN12195 and EN12642 Code XL. Ask DHOLLANDIA for further advice.



- **Pressure relief valve** [standard]. Safety device integrated in the pump unit, enabling the manufacturer and the installer of the tail lift to limit the real lift capacity to the maximum rated capacity of the tail lift sold, and to protect it against overload while LIFTING.


- **Pressure compensated flow valves** [standard]. Flow valves are integrated in the hydraulic circuits to ensure the platform lowers at a safe speed, both when empty as when fully loaded.

- **Marking of the centre point of maximum load** [standard]. Tail lifts are not designed to LIFT and LOWER weights corresponding to their maximum rated capacity over the entire surface of the platform. The maximum rated capacity is only valid at a specified distance or “centre point of maximum load” behind the vehicle body. Behind that point marked on the platform, the maximum safe working load diminishes according to the load diagrams supplied with the tail lift. See also section 8 on load charts and correct loading procedures.



- **Double cable system or load safety device (LSD)** [standard]. All column lifts must be protected from falling in case of accidental failure of the suspension system (steel cables or chain, sprocket, pulley, etc...). This protection can be:

→ **Double cable system + cable rupture detection** on most lifts type DH-VB / VO / VX with steel cables: suspension system with 2 steel lift cables plus 2 safety cables. If one of steel lift cables breaks, the platform is caught by the safety cable, and a cable rupture detection activated. From this moment onwards, the platform can only be lowered to offload any goods on the platform. An emergency button allows to LIFT and CLOSE the platform back in its travel position, and drive to a professional service agent. [see MAINTENANCE AND REPAIR MANUAL].



Double cable system (DH-VO)



Cable rupture detection inside cylinder beam (DH-VO)

→ **Load safety device (LSD)** on DH-VO lifts with chains or single cables: few DH-VO lifts are equipped with chains or a single-cable system. On such lifts, both lift runners are equipped with an LSD or chain-break or cable-break device. In the unlikely event of a steel rope or chain breaking, the LSD will jam the lift runner and the platform in the lift column, preventing the platform to drop more than 10 cm from its position at the time of the failure [see MAINTENANCE AND REPAIR MANUAL].

→ Note: the fully hydraulic lifts DH-VH are equipped with vertically positioned lift cylinders with electrical safety valves. They don't use steel cables or chains, and are not equipped with an LSD.

- **2-hand exterior control box** [standard]. On the exterior control box mounted in fixed position at the side of the vehicle body, all functions are actuated by means of a control switch and a safety switch. The compulsory use of the 2 hands to actuate the various lift functions, protects the operator from crushing his head, limbs or upper body between the LIFTING or CLOSING platform and the rear frame of the vehicle body.



- **Tail lift on/off switch** [min. 1 compulsory]. Depending on configuration, the electrical power to the tail lift is switched on / off by means of:

1. A **cabin switch** (provided by the truck manufacturer or DHOLLANDIA [option OAE503]). This switch enables the operator to switch the control power to the main exterior control box on / off. If equipped with a position sensor [option OAE502], it also provides a signal if the platform is stowed in its travel position, or left open.
2. A **main battery disconnect switch** integrated in the exterior control box [optional]. This switch enables the operator to switch the main battery power to the tail lift on / off. If available, the operator **MUST** switch off the main battery disconnect switch after each use of the tail lift.
3. A combination of both.



- **Fuses** [standard]. A 15A fuse for the electrical control circuit is premounted in the pump unit and in the main exterior control box (for most types). A 250-300 A fuse for the electrical main battery circuit is supplied by the truck manufacturer or by DHOLLANDIA. Both fuses protect the electrical circuits against short-circuits and amperage peaks.

- **Protection of toes and feet against crushing and sheering** [1 min. compulsory]. The tail lift standard EN1756-1 and DHOLLANDIA's fitting manuals provide a number of solutions to prevent the operator from crushing his toes or feet between in the inboard platform edge of the rising platform and the rear cross member of the vehicle floor.

Depending on the vehicle configuration (e.g. internal lifts), other crushing and sheering areas might exist. The vehicle manufacturer must ALWAYS make a thorough risk analysis of all possible pinch points and risk areas; and integrate solutions accordingly. DHOLLANDIA offers various solutions for specific applications. See page 4 for contact info.

Note: certain DH-VH lifts are not equipped with a toe-guard flap, and require further risk analysis by the vehicle manufacturer during the vehicle conception.




Standard toe-guard flap on exterior platform (DH-VO)

- **Foot controls** [optional]. Platform mounted foot controls (2 buttons or 4 buttons) immobilise the feet of the operator on a safe position on the platform, and protect him from crushing his toes or feet between in the inboard platform edge of the rising platform and the rear cross member of the vehicle floor.



- **Cart-stops** [optional]. If a platform is aimed at LIFTING and LOWERING loads that cannot be braked or secured by their design or their method of transportation, the platform MUST be equipped with cart-stops that prevent the load from accidentally rolling off the platform, and hitting the operator or any bystanders. DHOLLANDIA offers a variety of cart-stops that can be fitted near the outboard platform edge, or at intermediate distances.





- **Guard rails** [optional]. Guard rails MUST be fitted in all applications where a significant risk exists that the operator could fall off the platform and suffer bodily injury. They are compulsory above 2m lifting height.

Guard rails may be purchased along with your tail lift at the initial order, or may be purchased and retrofitted to your tail lift later. They are available in a wide range of different executions to suit the particular needs of many applications. Contact your national DHOLLANDIA dealer for further information. See page 4 for contact info.





- **Visibility of the deployed platform** [min. 1 compulsory]. Any platform protruding beyond the extremities of the vehicle, **MUST** be clearly visible from all approachable sides in daylight and at night. Check any applicable national or local regulations, as these can be very strict on the application, size and type of means used. The visibility of the platform can be optimized by:

1. **Reflective marking tape** applied to the sides of the platform [standard] applied during installation]
2. **Platform flags** [option OAT020 - 023], mounted to the underside of the platform, near the outboard platform edge
3. Bi-directional **flashing platform lights** [option OAE200], mounted on the platform surface, near the outboard platform edge
4. **Warning cones** (2 or 4) [widely available] placed around the work area of the platform
5. A combination of 2 or more of the above. The various means above have variable efficiency depending on the direction of approach and the light conditions (e.g. bright sunlight versus night darkness). DHOLLANDIA strongly recommends a combination of 2 or 3 means to cover all circumstances.



- **Decals** [standard]. The tail lifts are supplied with a number of operation decals, load diagrams and safety decals, most of them to be applied to the vehicle body during installation. These decals must be kept clean and legible at all times, and replaced whenever required.



7 SAFETY INSTRUCTIONS FOR USING THE TAIL LIFT

7.1 DO NOT USE TAIL LIFT WITHOUT ADEQUATE SAFETY AND OPERATOR TRAINING

- DHOLLANDIA tail lifts shall be exclusively used to load and unload the goods transported on the carrying vehicle, within the limits of the applicable load chart, in compliance with the operator instructions and safety instructions in this manual.

WARNING

- Improper use of the tail lift will put the operator and other parties at great risk of serious bodily injury and death.
 - To reduce the risk of serious bodily injury to the operator and any bystanders, the use of the tail lift is restricted to skilled operators, who have been properly trained, and who know and understand the full contents of this manual.
 - To reduce the risk of serious bodily injury or death, THE OPERATOR MUST COMPLY WITH ALL SAFETY INSTRUCTIONS AND WARNING LABELS IN THIS SECTION AND THE ENTIRE MANUAL before and while operating the tail lift.
- The operator should follow all other policies and procedures applicable to the job situation including health & safety regulations, road and traffic regulations, as well as company procedures. The operator should not use the tail lift if he/she cannot use it in accordance with all applicable regulations and instructions.
 - The operator shall be at least 18 years of age.

7.2 GENERAL SAFETY INSTRUCTIONS

WARNING



- To avoid serious bodily injury or death, the operator must use appropriate work clothes. NEVER wear loose-fitting clothes that may be trapped in the moving parts of the tail lift. ALWAYS wear professional safety-toe shoes, protective gloves, and eye protection. Use of hardhat is recommended.




- Slipping (and falling) can result in serious bodily injury and death. To prevent injury by slipping:
 - ALWAYS wear professional safety-toe shoes with a good non-slip sole.
 - DO NOT use the tail lift if it is covered with snow, mud, dirt, debris, liquids or other substances.
 - DO NOT run on the platform.
- Tripping (and falling) can result in serious bodily injury and death. To prevent injury by tripping:
 - DO NOT use tail lift platform as a step. NEVER leave the tail lift unattended in partially deployed position.
 - Pay attention to protruding items on the platform surface at all times (ex. platform lights, cart-stops and their levers, foreign objects, etc...).
 - DO NOT run on the platform.
- Falling from the platform can result in serious bodily injury and death. To prevent injury by falling:
 - Make sure your footing is solid and you maintain 3 points of contact. See 7.5 on page 34.
 - Use safety rails where available. See 7.5 on page 34.
 - NEVER move the vehicle while a person is standing on the platform or inside the vehicle body.
 - NEVER use the platform as an elevated working platform.

WARNING


- Prior to operating the tail lift, the vehicle must be safely parked on level and solid ground, the parking brake applied, and the engine must be switched off. Lock open the rear doors and secure all other moving parts of the vehicle body. Failure to abide by these instructions can result in serious bodily injury or death to the operator or bystanders.
- Ensure that the vehicle cannot tip-over when putting heavy weight on the platform. If the vehicle or the tail lift are equipped with mechanical or hydraulic stabilizing legs, deploy these before opening the platform. Ensure that the stabilizing legs are positioned on solid even ground. In case of soft terrain (sand, gravel,...), solid support blocks must be used under the stabilizing legs. Failure to abide by these instructions can result in serious bodily injury or death to the operator or bystanders.



- To reduce the risk of serious bodily injury or death which may result from other vehicles when parked, ALWAYS make sure a safety distance of 16 ft. or 5 m. is kept between the back of the truck and the following vehicle.



- To reduce the risk of serious bodily injury or death, ALWAYS make sure the platform is clearly visible to other persons from all approach directions. DHOLLANDIA recommends the use of 4 warning cones, placed around the work area of the platform. [See notice below].
- To reduce the risk of serious bodily injury or death, make sure the working zone is sufficiently lighted.



NOTICE

DHOLLANDIA offers optional platform mounted flashing lights and flags to make the platform more visible to other people. Please visit www.dhollandia.com or contact the national DHOLLANDIA distributor for more information. See page 4 for contact info.

WARNING

- Prior to releasing the mechanical platform lock (if so equipped) and using the tail lift, check if the tail lift can be used safely. Take precautions to ensure your own safety, and the safety of bystanders or other parties in traffic. Clear the working area of any objects that could potentially impede movement of the tail lift. Failure to abide by these instructions can result in serious bodily injury or death to the operator or bystanders.
- Inspect the tail lift prior to each use. If any unsafe condition exists or unusual noises or movements are noticed, DO NOT use the tail lift and contact an authorized DHOLLANDIA service agent for repair. Please see 'pre-trip inspection' procedures under §7.7 page 40.
- Read and comply with all warning decals, pictograms and instructions affixed to the tail lift. Failure to abide by warnings and instructions may result in serious bodily injury or death.
- The tail lift must not be used if the operator is intoxicated, impaired or distracted in any way. NEVER use a phone or mobile device when operating the tail lift.
- The tail lift shall be used by means of original control units only. Operating the tail lift with unauthorized control units will increase risk of serious bodily injury or death to the operator or any bystanders.
- Limit the operation of the tail lift to one single operator. Operation of the tail lift by more than one operator at a time may cause confusion and increase the risk of serious bodily injury or death.
- To prevent people from being hit by the platform, by objects falling off the platform or being caught in pinch points or being pinched by the moving parts of the tail lift:




→ Keep visual control over the entire working area of the tail lift and its platform at all times, including the area DIRECTLY BEHIND and UNDER the platform.



→ DO NOT allow any other person, to stand in the proximity of the tail lift and its platform. ENSURE AT ALL TIMES THAT NOBODY STANDS UNDER OR WITHIN REACH OF THE MOVING PLATFORM.

- When unloading from the vehicle body to the platform, ALWAYS push the load out, to prevent the load from hitting you. NEVER pull the load from the vehicle onto the platform. Pulling the load from the vehicle can result in a fall from the platform causing serious injury or death.
- If pushed out too far, the load can fall off the platform, and cause serious bodily injury or death to other people. Deploy the cart-stops before pushing out the load. If not available, push the load slowly while checking the outboard platform edges.
- The load must ALWAYS be secured when raising or lowering on the tail lift, to prevent it from shifting position and rolling off the platform edges. Failure to properly secure the load will increase the risk of serious bodily injury or death to the operator or any bystanders.
- When using a pallet jack, lower and rest the pallet or load upon the platform surface before operating the tail lift.
- For loads on wheels, engage wheel brakes of carts, trolleys and machinery (if available) before operating the tail lift.





WARNING



- For loads that could slip, the use of original DHOLLANDIA cart-stops or an appropriate alternative securement device (ex. ratchet straps) is required. The load must not be able to move during movement of the platform. See 9.9 for correct use of original DHOLLANDIA cart stops.
- NEVER leave the tail lift unattended in open position. Before leaving the vehicle unattended, close the doors of the vehicle, stow the platform in its travel position and switch OFF the main battery disconnect switch in the external control box (if so equipped), or the cab switch. Leaving the tail lift in open position unattended can result in serious bodily injury or death to unaware bystanders. See 9.5 for instructions on properly stowing platform into its travel position.
- NEVER move the vehicle with the tail lift in the open position. ALWAYS close and secure the doors of the vehicle, stow the tail lift in its travel position and switch OFF the main battery disconnect switch in the external control box (if so equipped), or the cab switch, before moving the vehicle. If so equipped, close the mechanical platform lock after stowing the platform in its travel position. Failure to properly stow the tail lift in its travel position prior to moving the vehicle may result in serious bodily injury or death.
- Use of the tail lift near vehicular traffic may result in serious bodily injury or death from being struck by another vehicle. When operating the tail lift on or near a street or parking lot, be sure to stay clear of vehicular traffic. ALWAYS be sure to clearly identify to other drivers that the tail lift is in use. DHOLLANDIA recommends use of warning cones to clearly identify to drivers that the tail lift is being operated. When the tail lift is operated near vehicular traffic, wear working clothes in high-visibility colors and a retro-reflective safety vest.
- DO NOT raise the tail lift with the rear doors partially open. Doing so may damage the doors or the tail lift platform and may also result in serious bodily injury or death to the operator or any bystanders.
- Above all, USE GOOD COMMON SENSE when operating the tail lift. DO NOT operate the tail lift until the contents of this manual have been read and fully understood. Improper use of the tail lift increases the risk of serious bodily injury or death to the operator and any bystanders.

NOTICE

- The safety instructions in this manual are drawn up with an average, common use of the tail lift in mind.
- For specific applications or work conditions, other instructions might be appropriate to reach a higher level of safety. If contra-indications exist, a formal risk analysis must be performed by the client's health and safety management and safe work procedures for the drivers and operators must be issued.

7.3 DANGER ZONES, RISK OF CRUSH AND SHEAR INJURY

- There are 4 main danger zones on and around the platform, that can be hazardous to the operator and any other persons nearby:




WARNING

Impact by the platform or the moving parts of the tail lift will result in serious bodily injury or death. To prevent people from being hit by the platform, by objects falling off the platform or being caught in pinch points or being pinched by the moving parts of the tail lift:



→ Keep visual control over the entire working area of the tail lift at all times, including the area directly behind and under the platform;

→ DO NOT allow any other person to stand near the tail lift and its platform. Ensure at all times that nobody stands under, or within reach of the moving platform and its load.



WARNING

Lowering an empty or fully loaded platform on one's feet may result in serious bodily injury. To prevent people from having their feet crushed or sheared by the lowering platform:




→ Keep visual control over the entire working area of the tail lift at all times, including the area directly behind and under the platform;

→ When operating the tail lift from a position on the ground, ALWAYS stand at the side of vehicle body, at a safe distance of minimum 50 cm away from the moving platform.

3




3. Beware of the crushing zone between rising platform and vehicle floor




4



4. Beware of the crushing zone between closing platform and rear frame of vehicle body



WARNING



- If the operator on the platform stands too close to the inboard platform edge, protruding toes might be crushed or sheared between the rising platform and the cylinder beam or vehicle floor. This can cause serious bodily injury.
- Therefore, when operating the tail lift from a position on the platform, ALWAYS stand at a safe distance of min. 25 cm from the inboard platform edge.
- NEVER reach over or through the platform and the moving parts of the tail lift while trying to operate the lift. ALWAYS keep your head, limbs and body clear of the moving platform and other pinch points.



WARNING



- If the operator enters the zone between the closing platform and the lift columns with his head, upper body or limbs, protruding body parts may be hit, crushed or sheared by the closing platform. This will cause serious bodily injury or death.
- Therefore, while stowing the platform in its travel position, ALWAYS stand with both feet on the ground on a free-standing, safe operator position at the side of the body and ALWAYS keep head, limbs and upper body clear of hazardous space between the platform and the lift columns.
- NEVER reach over or through the platform and the moving parts of the tail lift while trying to operate the lift. ALWAYS keep your head, limbs and body clear of the moving platform and other pinch points.

4 [continued]. Most column lifts are equipped with a device that shut closes the platform tight against the lift columns, after it was tilted in the vertical position and while it is lifted in its travel position.

Therefore, again, while stowing the platform in its travel position, ALWAYS stand with both feet on the ground on a free-standing, safe operator position at the side of the body and ALWAYS keep head, limbs and upper body clear of hazardous space between the platform and the lift columns.

⚠ WARNING	
	<p>When stowing platform in travel position, platform will automatically shut close at the end of its vertical travel.</p> <p>ALWAYS stand on the side of the vehicle, and stay clear of the platform area.</p> <p>ALWAYS keep head, limbs and body clear of pinch points.</p>
DHOLLANDIA • EF0567 EN	

4 [continued]. In case of platforms equipped with manual closure and automatically folding guard rails (sides only), or gas-bottle execution (sides + rear), make sure you use the grab handle on the guard rail to open and close the platform.



⚠ WARNING	
	<ul style="list-style-type: none"> Opening and closing of the platform by holding the steel members of automatically folding guard rails can crush the operator's hands between the moving elements of the guard rail. To avoid bodily injury, always use the grab handle to manually open or close the platform and its guard rails, and beware of pinch points at all times.


⚠ WARNING	
	<p>The operator or other persons approaching too close to these danger zones risk serious bodily injury or death by pinching, crushing or shearing of limbs, upper body or head. To prevent these hazards:</p> <ul style="list-style-type: none"> → ALWAYS stand clear of the range of motion of the platform and moving parts of the tail lift; → Keep hands, feet and upper body clear of pinch points and moving parts of the tail lift; → DO NOT allow any other person to stand near the tail lift and its platform.

7.4 ADDITIONAL RISKS OF LIFTING ABOVE THE VEHICLE FLOOR LEVEL

- The tail lift's capacity to travel above the vehicle floor level can cause additional risks that must be taken into account by the operator while using the tail lift. ALWAYS pay special attention to the following issues.


7.4.1 Risk of falling

- Multi-deck lifts usually travel up to a much higher distance above the ground than conventional tail lifts. The potential consequences of an accidental fall aggravate with the increased lifting height. Falling from heights can cause serious bodily injury or death.
- Tail lifts lifting higher than 2 m above ground level must be equipped with guard rails along the exposed edges of the platform. For tail lifts with a lower range, DHOLLANDIA recommends that guard rails be used to mitigate the risk of falling.
- Guard rails may be purchased along with your tail lift at the initial order, or may be purchased and retrofitted to your tail lift later. Please see www.dhollandia.com for further information or contact your national DHOLLANDIA distributor. See page 4 for contact info.

 WARNING	
 	<ul style="list-style-type: none">• Falling from heights can cause serious bodily injury or death.• To prevent injury or death by falling from the platform:<ul style="list-style-type: none">→ ALWAYS make sure your footing is solid;→ ALWAYS hold onto the guard rails;→ ALWAYS maintain 3 points of contact.
	


7.4.2 Risk of other persons standing under the platform

- Multi-deck lifts usually travel up to a much higher distance above the ground than conventional tail lifts. Therefore, there is a greater risk that somebody could stand under the platform while the platform is situated high above the ground. Lowering the platform onto a person will cause serious bodily injury or death.
- Tail lifts lifting higher than 2 m above ground level must be equipped with a sound alarm, activated whenever the platform is lowered.
- For internal lifts or the internal platforms of combined external + internal lifts, loading and unloading **MUST** be restricted to one single person to avoid persons standing or walking below the platform while the operator is using the internal platform.

 WARNING	
 	<ul style="list-style-type: none">• If platform is lowered onto a person, this will cause serious bodily injury or death.• To prevent bodily injury or death by a platform lowering onto a person:<ul style="list-style-type: none">→ NEVER allow any other person to come near the working area of the tail lift and its platform;→ ALWAYS keep visual control over the entire working area of the tail lift and its platform;→ For internal platforms, NEVER allow any other person inside the vehicle body when using the tail lift.→ Before lowering, ALWAYS inspect the area UNDER and BEHIND the platform. <div style="display: flex; justify-content: space-around; align-items: center;"><div style="text-align: center;"></div><div style="text-align: center;"></div></div>

7.4.3 Risk of crushing and shearing


- For all brands and types of tail lifts, there is risks of crushing and shearing toes and feet between:
 - the rising platform and the vehicle floor (see 1 on right side),
 - or between the lowering platform and the ground (see 2 on right side).
- The operator must ALWAYS stand on a safe operator position while using the tail lift. See also §7.3 from page 26 onwards and §7.5 from page 34 onwards.
- Additional risk exists on multi-deck lifts for any person standing inside the vehicle body, or present in the scissor zone between the moving platform and the vehicle floor (or one of the vehicles floors in case of a multi-deck vehicle).
- Any person caught and crushed between the moving platform and the vehicle floor will suffer seriously injury or death (see 3 below).
- Any person standing inside the vehicle body, with feet protruding beyond the outboard edge of the vehicle floor, will suffer severe crushing and shearing of his feet or toes by a platform travelling down from a higher position, resulting in serious bodily injury (see 4 on right side).



⚠ WARNING	
	<ul style="list-style-type: none"> Any person standing on the platform or inside the vehicle body, too close to the moving platform, risks being crushed or sheared between the moving platform and the vehicle floor, and can suffer serious bodily injury or death. To prevent injury or death by crushing or shearing: <ul style="list-style-type: none"> → When standing on the platform, ALWAYS stand at a safe distance of min. 25 cm from the inboard platform edge; → When standing inside the vehicle body, ALWAYS stand at a safe distance of min. 25 cm from the outboard edge of the vehicle floor; → NEVER step in or out of the vehicle body while the platform is in motion. → Before moving the platform, ALWAYS inspect the area UNDER and AROUND the platform.


- Unless specified differently by the client, DHOLLANDIA external column lifts DH-VB / VO / VX are equipped with a safe toe-guard flap with detection switch [ref. OVP401] where possible.


- For the operator on the platform, this flap stops the LIFT movement if a person or an object stands on the flap, and prevents that his feet are crushed between the raising platform and a fixed vehicle floor or roof.
- For the operation standing inside the vehicle, this flap tilts up when hitting an obstruction such as the operator's feet, and prevents his feet from being crushed between the lowering platform and the vehicle floor.
- This toe-guard flap is a safety feature. It is forbidden to stand on it or place load on it.



- As alternative for these DH-VB / VO / VX lifts, both the platform and the subsequent vehicle floors may be equipped with a hinged toe-guard flap [ref. OVP403 / 404].

- For the operator on the platform, the flap attached to the vehicle floor tilts up when hitting an obstruction such as the operator's feet, and prevents his feet from being crushed between the raising platform and the vehicle floor.
- For the operator standing inside the vehicle, the flap attached to the platform tilts up when hitting an obstruction such as the operator's feet, and prevents his feet from being crushed between the lowering platform and the vehicle floor.
- These toe-guard flaps are a safety feature. It is forbidden to stand on it or place load on them.




 WARNING	
	<ul style="list-style-type: none"> The requirement to ALWAYS stand clear of the moving platform and the floors or roof of the vehicle applies to all multi-deck lifts. This requirement applies to DH-VH fully hydraulic lifts IN A CRITICAL WAY, since the application and their design for special multi-deck vehicles with extreme deck heights sometimes makes use of the above mentioned toe-guard protection systems impossible. (see note below)

- Note on DH-VH: where possible, the vehicle manufacturer shall install alternative safety systems, such as infrared or equivalent safety fences.

7.4.4 At the vehicle roof


- The risk of crushing and shearing is not only prevalent between the moving platform and the various floors, but also applies at roof level.
- Therefore, also at roof level the safety precautions of chapter 7 must be strictly followed.



7.4.5 Special attention for overhead cross tube between the lift runners




- Certain column lifts, such as some of the DH-VH models, are equipped with a cross tube mounted between the top extremities of the L+R lift runners, travelling up and down together with the lift runners
- When moving up and down, this cross tube can come in contact with fixed parts of the vehicle floor or roof.
- Particularly when LIFTING a DH-VH to its maximum height, this cross tube will encroach into the overhead cross member of the roof. Therefore, any person laying his hand(s) on this cross tube risks crushing his hands between the moving rising cross tube and the vehicle roof.

 WARNING	
	<ul style="list-style-type: none">• For lift runners equipped with a cross-tube at the top, resting the operator's hand on this cross-tube can lead to serious hand injuries when moving the platform up and down.• To avoid this risk, NEVER use this cross-tube as a handhold.• ALWAYS make sure your footing is stable, and hold any free hands onto the dedicated guard rail.




7.5 SAFE OPERATOR POSITION


- The instructions on safe operator position aim to enforce that the operator stands in a safe position before and while operating the tail lift, and protect him against the risks of crushing and sheering as described in chapter 7.
- Main external control box:** the zone just in front of the side-mounted external control box, is the only position from where the operator can safely OPEN and CLOSE the platform. It is also safe to LOWER and LIFT the platform from this position.
- Auxiliary controls:** the operator may also lower and lift the platform through use of the auxiliary controls. The operator must use **extreme caution** when lowering or lifting the platform with the auxiliary controls and must ensure it is done from a safe position. Use of auxiliary controls from an improper position greatly increases the operator's risk of crushing or sheering of toes, limbs, head, and upper body as well as death. See §7.3-7.4 from page 26 onwards regarding Danger zones, risk of crush and shear injury.
- Depending on options chosen, the guard rails on the platform can be equipped with fixed auxiliary LIFT / LOWER controls.
- This set-up keeps the operator's feet at a safe distance from crushing zone at the inboard platform edge, and encourages him to use the guard-rail to enhance his personal stability on the platform.
- While travelling on the platform, the operator must ALWAYS observe the safety precautions below.



 WARNING	
	<ul style="list-style-type: none"> If not standing solidly, an operator on the platform risks serious injury or death by falling off. While riding on the platform, ALWAYS make sure your footing is solid, and ALWAYS maintain 3 points of contact, as shown in the image on the right.
	<ul style="list-style-type: none"> When reaching out your hand for a 3rd point of contact, ALWAYS stay clear of the open lift columns and the moving lift runner, chains, and sprockets. ALWAYS hold onto the guard rails as a safe 3rd point of contact.



- If handheld auxiliary controls with a spiral cable are used, the following conditions must be met (1):




On the platform, from a safe operator position of minimum 40 x 40 cm square, clearly and permanently marked at minimum 25 cm distance from the hazard zone between the platform and the rear of the vehicle floor. Maintain 3 points of contact (see above).

Inside the vehicle body, from a safe operator position of minimum 40 x 40 cm square, clearly and permanently marked at minimum 25 cm distance from the hazard zone between the platform and the rear of the vehicle floor.

On the ground, from a safe operator position minimum 50 cm away from the side edge of the platform.

(1) Remark: The CE standard EN1756-1 suggests a number of other, less usual solutions providing sufficient protection against crushing and sheering of the toes and feet, such as a hinged foot protector or cut-out switch. Consult the latest edition of DHOLLANDIA's fitting instructions FIT-ELEC-OPTION or contact your national DHOLLANDIA dealer for more information. See page 4 for contact info.

- A fixed internal control should only be used inside the vehicle body from a safe operator position that is a minimum 40 x 40 cm square, clearly and permanently marked at a minimum of 25 cm from the hazard zone between the platform and the rear of the vehicle floor (see (1) on previous page). A fixed internal control should NEVER be used from a position on the platform.
- The marked operator positions on the platform must be kept clear at all times. It is prohibited to place a load on these dedicated areas.



- The power to any of the auxiliary controls (hand held controls or platform mounted foot controls) must be connected to and dependent upon the safety switch in the main external control box. Activation of the auxiliary controls must deactivate the functions on the external control box.
- It is prohibited to bypass or modify any of the safety features of the tail lift. If connection of the power to the external control box does not deactivate external controls, stop using the tail lift, and contact an authorized DHOLLANDIA agent to rectify.



WARNING


- When standing in front or behind the load, the operator risks being pushed off the platform, or being crushed between the moving load and the rear frame of the vehicle body, resulting in serious bodily injury or death.
- To prevent this hazard, ALWAYS stand on the side of the load, NEVER in front or behind.

7.6 INSTRUCTIONS FOR WORKING AT LOADING DOCKS


WARNING

- Improper use of the tail lift may result in damage, premature wear or failure of the tail lift, and will increase the risk of serious injury or death to the operator and other persons nearby.
- In order to maximize the durability, ensure long-term reliability of the tail lift, and protect operators and bystanders from serious bodily injury or death, the operator must comply with the loading instructions and safe working procedures below.


There are 3 main ways of handling a column lift at the loading docks:




1. Platform lowered below the vehicle floor level. All cargo is loaded / unloaded over a dock-plate that links the dock and the vehicle floor.



2. Platform is used as a loading platform; or as a bridge plate (in case of optional tilt cylinders)



3. Platform is hidden in a pocket or briefcase under the loading dock. All cargo is loaded / unloaded over a dock-plate that links the dock and the vehicle floor.




When the intention is to dock with the platform lowered below the vehicle floor level, DO NOT lower the platform until the vehicle is standing on flat even ground. ALWAYS reverse slowly, and make sure you maintain sufficient ground clearance between the lowest part of the tail lift and the ground. Take into account variations in the suspension and vehicle height.

NOTICE


- When reversing a vehicle with column lift into a loading dock, ALWAYS make sure there is sufficient ground clearance between the lowest part of the tail lift and the ground.
- ALWAYS reverse slowly, and avoid hard dock impact on the tail lift.
- Reversing with insufficient ground clearance, or with too hard dock impact may result in severe damage to the tail lift.

When the intention is to use the platform as a loading platform or bridge plate, the following instructions apply:


2




The tail lift can only be used as a loading platform if the dock is lower than the vehicle floor.



Unless the vehicle suspension can be blocked (e.g. by means of hydraulic stabilising legs) and the floor maintained at the original height vfh, the max. load transferred over the platform should not exceed 500 kg. Exception: column lifts with 2 tilt cylinders [option OVH011].




The tail lift can be used as a bridge plate, if it is equipped with the optional tilt cylinders with adjustable platform orientation [OVH011].




It is forbidden to drive forklifts or heavy electric pallet jacks over the platform.


The total weight of the load and the lifting device must not exceed the maximum rated capacity of the tail lift. Beware not to overload!




A minimum section of 15 cm of the outboard platform edge must cover the loading dock.



If the loading floor of the vehicle lowers or rises relative to the loading dock, use the electrical controls to adjust the platform position flush with the loading dock surface.



NEVER use a foldable platform as a bridge plate between the vehicle floor and a loading dock. Keep the platform securely stowed in its travel position to avoid damage.




NEVER use a dock plate on top of a floating platform as a bridge between the loading dock and vehicle floor.



WARNING



- ALWAYS stand with both feet on the ground on safe operator position at the side of the body when operating the exterior control box (see also §7.5) or the platform locks. NEVER operate the exterior control box or the platform locks from an elevated position, such as the platform or a loading dock.
- NEVER reach over or through the platform and the moving parts of the tail lift while trying to operate the tail lift. ALWAYS keep your head, limbs and body clear of the moving platform and other pinch points.





3


When the intention is to stow the platform in a pocket or brief case

under the loading dock, observe following points before reversing into the dock:

- Make sure the pocket is deep enough for the depth of the platform.
- Make sure there is sufficient clearance above and below the platform, taking into account all possible variations in vehicle suspension and vehicle floor height.
- Make sure the platform does not touch the ceiling, ground or end wall of the pocket.



OVERLOAD



Whenever cargo is loaded or offloaded with forklifts, electric pallet jacks, and the total weight of the load plus handling equipment exceeds the maximum rated capacity of the tail lift, ALWAYS use a dock plate from the loading dock to the vehicle floor, and safely stow the lift below the vehicle floor level, or in the pocket or brief case under the loading dock.

7.7 RECOMMENDED DAILY PRE-TRIP INSPECTION



WARNING

- Using a tail lift that is damaged or improperly serviced can put the operator and bystanders at great risk of serious bodily injury and death.
- To avoid this risk, inspect the tail lift prior to the first use of each day. Ensure that all safety systems and all functions operate correctly, and that no maintenance or repair is required.
- If any unsafe condition exists or unusual noises or movements are noticed, DO NOT use the tail lift, and contact an authorized DHOLLANDIA agent. [see Notice].
- DO NOT cover up any accidents or damage; it can be dangerous to you, your co-workers, and other persons.

NOTICE

Authorized DHOLLANDIA service agents may be found at www.dhollandia.com or by calling your regional DHOLLANDIA distributor. See page 3 for contact info.

Before operating the tail lift, the operator must conduct the following daily pre-trip inspection. Use caution: stay clear of the area directly behind the platform while conducting the daily pre-trip inspection.

- Replace missing, worn or illegible warning decals immediately. See page 3 for contact info.
- Make sure the cabin switch and / or main battery disconnect switch in the control box switch on and off accordingly.
- Make sure the battery is fully charged, the main fuse is in good condition, and battery terminal connections are corrosion-free and tight.
- Check the overall condition of the main external control box and its switches. Confirm that all switches (except the ON / OFF cabin switch) swiftly return to the neutral position after releasing them.
- Check the overall condition of the cables entering the various control units, and of the cables to the pump unit. Make sure cables are not chafed, loose or damaged.
- Ensure the cover of the pump unit is properly installed and secured.
- Check the pump unit for visible oil leaks.
- Check if the platform is standing tight and straight between the columns (no cables, chains or pulleys damaged).

Follow the instructions in section Error! Reference source not found. to open and lower the platform to the ground, and continue the checks:

- Visually inspect the general condition of the lift frame, lift runners, the mounting bolts or welds to the rear frame of the vehicle body. Look for cracks or deformation in the material and welds. If bolted, make sure the bolts connecting the lift frame to the rear frame of the body are tightened.
- Visually inspect the columns and lift runners. For cables, visually inspect that the cables don't look damaged or unraveled. Check if the platform hangs level with the vehicle floor. Make sure the inside of the columns is free of sand, dirt or debris.
- Make sure all pivot pins are properly locked and secured.
- Visually inspect the general condition of the platform, and its folding or slide-out ramp if applicable. Look for cracks or deformation in the material and welds. If so equipped, make sure the platform-mounted options function correctly (cart-stops, foot controls, flashing warning lights).
- Check the general condition and operation of the guard rails and their controls. Look for cracks or deformation in the material and welds. Ensure they remain locked in the raised position after deployment.
- Check the general condition and operation of the toe-guard flap at the inboard platform edge. Ensure it can tilt up and down freely. Verify, without protruding your foot over the inboard platform edge, that the LIFT function is interrupted when the flap is pushed down.

- For lifts with manual closure: check the operation and overall condition of the stow lock and platform lock.
- For lifts with manual closure: Check the operation and overall condition of the torsion bars. The platform can be manually opened and closed without excessive effort.
- Check the overall condition of the auxiliary controls and their switches. Confirm that all switches swiftly return to the neutral position after releasing them. In case of a handheld control with spiral cable, inspect the spiral cable for wear or damage.
- Make sure safe operator position and center point of maximum load are clearly marked on the platform.
- Make sure the platform surface is clean and can be accessed safely. Remove any snow, mud, dirt, debris, or slippery liquids. Make sure you wear safety-toe shoes with a good non-slip sole.
- Check the cylinder beam and optional tilt cylinders, their lock valves and fittings for visible oil leaks. Follow the hydraulic pipes and fittings to the pump unit. Make sure all wires and hydraulic pipes are undamaged, not pinched or chafed anywhere, and adequately secured with cable ties. Check for visible oil leaks.

Perform all movements with an unloaded platform several times with all available control units. Use the operation manual for guidance.

- Make sure all movements occur smoothly and quietly, without jerking motion or unusual noises. During LIFT and CLOSE functions, only the sound of the electric motor in the pump unit should be audible.



Remember: if any part of the pre-trip inspection reveals a need for service or repair

→ **DO NOT use the tail lift until it has been serviced or repaired by a qualified service technician.**

→ **Switch OFF power at the main battery disconnect switch or cabin switch [see §9.4 on page 52].**

7.8 IMPORTANCE OF PREVENTATIVE MAINTENANCE

NOTICE

- Competent and regular preventative maintenance is essential to the operational reliability of the tail lift as well as the safety of the operator and all bystanders.
- All maintenance and repair work must be performed by authorized DHOLLANDIA service agents, and using original DHOLLANDIA replacement parts only.
- Please consult the separate MAINTENANCE AND REPAIR MANUAL for specific instructions regarding periodic maintenance.

- If a tail lift cannot be repaired immediately in case of breakdown, it must be put out of operation and secured against unauthorized use.
- A tail lift put into its travel position with the help of external devices (forklift, gantry crane,...), is not supported by its hydraulic cylinders. After releasing the mechanical platform lock, the platform and lifting mechanism will drop in free fall, without any possibility to stop the fall by means of the regular controls.

WARNING



Impact by a falling platform will result in serious bodily injury or death. To reduce the risk of injury:

- Close the platform lock (if available), and apply additional means to immobilize the platform [see note below].
- Attach a clear and highly visible warning tag to the platform and the exterior control box.
- Warn your supervisor and have this vehicle put out of service
- Contact an authorized DHOLLANDIA service agent to repair the tail lift prior to any further use.

- Note: examples of additional means are additional securing of the platform lock (if available), or securing the platform by means of ratchet straps, hoists, etc.
- To re-open the tail lift, use again an external device (forklift, gantry crane,...) for additional support. Or repair the breakdown first, bring the hydraulic system under pressure, and release the platform locks after satisfactory testing of the hydraulic integrity. Follow the MAINTENANCE MANUAL for all maintenance and repair works.

8 LOAD CHARTS AND CORRECT LOADING PROCEDURES

NOTICE



- Tail lifts are NOT designed to LIFT / LOWER weights corresponding to their **maximum rated capacity** over the **entire** surface of the platform. The maximum rated capacity is valid at a certain distance or **center point of maximum load** behind the vehicle body. Behind that point marked on the platform, the maximum safe working load diminishes according to the load charts below.
- When LIFTING, the tail lift is normally protected against overload by the pressure relief valve in the hydraulic circuit. Most of overload events and resulting damage happen when LOWERING loads.

! WARNING

- Overloading and improper loading and unloading of the tail lift will put the operator and bystanders at great risk of serious bodily injury or death. Such conditions will also cause premature wear and damage to the tail lift, or failure of the tail lift.
- Therefore, it is essential that the operator respects the maximum rated capacity and follows the loading instructions and the load chart with great care.
- DHOLLANDIA disclaims liability for all personal bodily injury and / or property damage that results from overloading practices.

- The **maximum rated capacity** is the maximum weight that the tail lift can carry under the following best possible circumstances:
 - the center of gravity of the **load** stands no further than the designated center point of maximum load of the **tail lift**, marked on the platform surface, and
 - the load stands mid-point between the lift arms, and is at equal distance from both platform sides.

NOT OK
NEVER position the load at the outboard platform edge .





OK
ALWAYS position the load as close as possible to the rear of the vehicle, near the inboard platform edge.



- Uneven loading on one side of the platform should be avoided. Limit the load to 50% of the max. rated capacity when loading on one side of the platform only.

NOT OK
NEVER load on one side of the platform only .
Or limit load to 50% of maximum rated capacity.




OK
ALWAYS position the load mid-point between the lift arms.

- The maximum **safe working load** GOES DOWN according to the load charts. The following type of load chart decals are supplied with the tail lift, and must be duly observed.

EXAMPL



EXAMPL



PLATFORM LOADING INSTRUCTIONS

Position load as close as possible to inboard platform edge.

Position load in middle line of platform. Avoid loading on 1 side only.

Operator should stand on side of load, well clear of inboard platform edge to avoid crushing feet.

Read and understand the user's manual, all instructions and warnings before use.

DHOLLANDIA EF0564-EN

⚠ WARNING

- Overloading and improper loading and unloading of the tail lift will put the operator and bystanders at great risk of serious bodily injury or death. Such conditions will also cause premature wear and damage to the tail lift, or failure of the tail lift.
- Pay attention to avoid concealed overload situations as shown in examples below. Serious bodily injury or death may result from failure to abide by these warnings.


⚠ OVERLOAD

⚠ OVERLOAD


- NEVER let the load extend beyond the outboard edge or side edges of the platform.
- NEVER let the wheels of a pallet jack extend or drop down beyond the outboard or side edges of the platform. Keep the pallet jack and its load on the platform surface, as close as possible to the inboard platform edge. Lower and rest the pallet or load on the platform surface to prevent it from shifting position while lifting and lowering.

! WARNING


- Lower and rest the pallet or load on the platform surface to prevent it from shifting position while lifting and lowering.




- NEVER drop any load on the platform (ex. by means of a forklift, gantry crane, etc...). The impact of dropping a load is far greater than the nominal weight of the load and can cause severe damage to the tail lift.




- NEVER drive a forklift onto the platform. Driving a forklift onto the platform can cause severe structural damage, potentially invisible to the operator at first glance. Further use of an overloaded or damaged platform can put the operator and bystanders at great risk of serious bodily injury and death.



- NEVER try to scoop loose material (ex. sand, gravel, rocks, etc...) from the ground, to attempt to move it by means of the platform, or to lift / lower it on the platform.



- NEVER use the platform to level the ground surface, or to push or pull loads or material by means of the platform. NEVER use the platform to move snow or other debris.




9 OPERATING INSTRUCTIONS – PRINCIPLES AND PROCEDURES

9.1 PLATFORM RIDE

- The ride of a tail lift describes the movement that its platform goes through when lifting and lowering. All multi-deck column lifts are equipped with a flat platform level ride.
- While the platform travels up and down, the angle between the platform and the columns remains unchanged. If the vehicle is standing level on flat, even ground, the platform will travel up and down level with the ground.
- The majority of these column lifts are equipped with 2 tilt cylinders [ref. OVH001 or OVH002]. That enables the operator to open and close the platform hydraulically from the main external control box, and to adjust the pitch of the platform to the slope of the ground, or to tilt the platform towards a loading dock.
- Some of these column lifts are equipped with manual closure or with 1 tilt cylinder [ref. OVH003 - OVH004]. In both cases, the platform pitch is not adjustable. (Platform is fully closed at 90° or fully open at 0°).
- In case of manual closure, the platform is opened and closed manually, with assistance of one or more torsion bars inside the platform. Refer to the operation manual of the DH-VO*K9 lifts for important safety instructions on manual closure lifts. Copies of that manual can be obtained from the national DHOLLANDIA distributor. See page 4 for contact info.
- Option OVH003 - OVH004 (= 1 tilt cylinder) enables the operator to open and close the platform hydraulically instead of manually, but the pitch of the platform is not adjustable. (Platform is fully closed at 90° or fully open at 0°).

Manual closure -


Hydraulic closure with 1 tilt cylinder OVH003-OVH004



→ Fixed platform orientation

Hydraulic closure with

2 tilt cylinders OVH001-OVH002




→ Adjustable platform orientation

WARNING

- It is important for both types of tail lifts that loads on wheels, or loads that could easily shift position and fall from the platform, are properly secured on the platform surface prior to operating the tail lift. See also §9.9 from page 65 onwards.
- For lifts with non-adjustable platform pitch, it is exceptionally ESSENTIAL that the operator ensures that cart-stops or retention ramps are deployed (if available), wheel stops or brakes are activated, or the load is secured on the platform in a different way prior to operating the tail lift.
- Improperly secured loads could fall off the platform, and put the operator and bystanders at great risk of serious bodily injury and death.


9.2 MAIN EXTERNAL CONTROL BOXES

- All images, pictograms and decals in this manual represent the version for left hand drive vehicles, with the main external control box mounted on the right side of the vehicle
- DHOLLANDIA offers various control boxes, delivered per customer specification. Contact the national DHOLLANDIA distributor for more information, prior to ordering your tail lift. See contact info on page 3.
- All standard external control systems are equipped with mandatory 2 hand operation, and are mounted at the side of the vehicle body, in order to:
 - prevent the operator from standing behind the platform when opening the platform which could result in serious injury or death by crushing.
 - prevent the operator from crushing his / her limbs, upper body or head between the platform and the rear frame of the vehicle when closing the platform.
- The most popular models are outlined below. Contact the national DHOLLANDIA distributor for operation instructions on other models, or models with different options, prior to operating the tail lift. See contact info on page 3.



1	Joystick operating the functions OPEN - LOWER - LIFT - CLOSE
2	Rotary safety switch to activate the joystick, or to switch over to the auxiliary control
3	Main battery disconnect switch (optional) to switch the main power from the battery to the pump unit of the tail lift on / off. <ul style="list-style-type: none"> Will stop the tail lift in case of emergency involving hazard to operator or bystander. Will stop the tail lift and reduce the risk of a pump unit burn-out if the motor solenoid is stuck and the motor runs continuously (control button or contact damaged, motor solenoid short circuited by low voltage.)

Operation:



Arctic control box (ref. OAE041.BP)




2 Push and hold to activate push buttons of main external control box
Release to enable auxiliary control

3 Turn clockwise to switch battery power ON
Turn counter-clockwise to switch battery power OFF

1	Push buttons commanding the functions OPEN - LOWER - LIFT - CLOSE
2	Safety switch to enable the push buttons, or to switch over to the auxiliary control
3	Main battery disconnect switch (optional) to switch the main power from the battery to the pump unit of the tail lift on / off. <ul style="list-style-type: none"> Will stop the tail lift in case of emergency involving hazard to operator or bystander. Will stop the tail lift and reduce the risk of a pump unit burn-out if the motor solenoid is stuck and the motor runs continuously (control button or contact damaged, motor solenoid short circuited by low voltage.)

Operation:



Hydraulic stabilising legs (ref. OAH01...)




When the tail lift is equipped with hydraulic stabilizing legs, the control units above are completed by a turn switch to push the legs down or pull them up.

1	Turn switch commanding the functions LEG DOWN - LEG UP
---	---

On OAE030... units

On OAE041... units

Operation:




- Other control boxes with compulsory 2-hand controls feature push buttons or toggle switches to control the various functions OPEN - LOWER - LIFT - CLOSE. The units are not available with an integrated main battery disconnect switch.


Flush mount control unit (ref. OAE031.ZP)




Operation:




Flush mount control unit (ref. OAE033.Z) for tail lift with hydraulic retention ramp (ref. OVP152)




Operation:



Dual toggle-switch control box (ref. OAE044.ZP)



Operation:



⚠ WARNING

- Handheld 3-button or 4-button controls, enabling the operator to OPEN and CLOSE the platform, can be operated from an unsafe operator position (see §7.3 from page 26 onwards).
- If used from an unsafe operator position, the use of such handheld controls will put the operator at great risk of serious bodily injury and death. To prevent these risks:
 - NEVER OPEN the platform while standing behind or in the range of motion of the platform
 - NEVER CLOSE the platform, while standing close to the crushing zone between the closing platform and the rear frame of the vehicle body.
 - Only use the handheld 3-button or 4-button controls with extreme caution.
- DHOLLANDIA strongly discourages the use of handheld 3-button or 4-button controls. They should only be used after adequate risk analysis by the vehicle owner or his authorized occupational health and safety manager, and under guidance of safe work practices issued by them.

9.3 AUXILIARY CONTROLS

⚠ WARNING



- To reduce the risk of injury to the operator or any bystanders, the auxiliary controls must only be used from a safe operator position on or beside the platform, conforming with the safety precautions described in section 7.
- Any operator on the platform must stand clear of the crushing zone between the lifting platform and the rear of the vehicle floor.
- Any operator on the ground must stand clear of the crushing zone between the lowering platform and the ground.
- Keep head, hands and feet clear of pinch points and moving parts. Beware of hand, foot and head traps at all times.
- NEVER wear loose fitting clothing when operating or standing near the tail lift as it increases the risk of serious bodily injury and death.
- ALWAYS be aware of vehicular traffic when using controls to operate the tail lift.
- Failure to abide by these warnings may result in serious bodily injury or death to the operator or any bystanders.

Toggle-switch controls [ref. OAE015.0]


- DHOLLANDIA recommends the use of the LIFT / LOWER controls integrated in one of the guard rails on the platform.



Operation:




- Similarly, if the platform is equipped with a hydraulic retention ramp [ref. OVP152], that ramp is raised and lowered by a toggle switch [ref. OAE015.O]




- DHOLLANDIA offers various other types of auxiliary controls, delivered to customer specification. Contact your national DHOLLANDIA distributor for more information, prior to ordering your tail lift. See contact info at page 3.
- The most popular options are outlined below. If missing in this overview, contact your national DHOLLANDIA distributor for operation instructions on other models, or models with different configurations, prior to operating the tail lift. See contact info at page 3.


2-button handheld control with spiral cable (ref. OAE001)




2-button interior control (ref. OAE003 / OAE005 / OAE012)



4-button foot controls on platform (ref. OAE060 / OAE064)



2-button foot controls on platform (ref. OAE067)



9.4 SWITCHING THE MAIN POWER ON / OFF

- Depending on configuration, the power to the tail lift can be switched ON / OFF by means of a cabin switch, a main battery disconnect switch, or a combination of both.

Cabin switch

example



Push button to switch tail lift power ON (indicator light on)
Push button to switch tail lift power OFF (indicator light off)

If platform is equipped with a tilt sensor, indicator light can be configured to switch on if platform is not closed in its travel position.

Main battery disconnect switch



Turn clockwise to switch battery power ON

Turn counter-clockwise to switch battery power OFF

NOTICE

In case of combined system, (main battery disconnect and cabin switch) both must be switched on to activate the tail lift. Switching off only one of two will deactivate the tail lift, but it is strongly recommended to switch-off both. NEVER leave the main battery disconnect switch on while tail lift is not in use.


9.5 OPERATION OF THE STANDARD MULTI-DECK COLUMN LIFT WITH HYDRAULIC CLOSURE

- §9.2 through §9.3 explain how the functions OPEN - LOWER - LIFT - CLOSE are executed via the various types of controls and how the optional stabilizing legs are operated. This section explains in which sequence the DH-V* must be operated, and which steps must be followed.
- The images shown refer to instruction decal ref. EF0599.EN, usually affixed to the side of the vehicle body. See also section 10 on page 68.

Opening the platform




Consult the operation manual before getting started. Follow **ALL** safety and operation instructions.




Switch on the electrical power to the tail lift (cabin switch or main battery disconnect switch in the external control box, or both if both are available).




If so equipped, LOWER the mechanical or hydraulic stabilizing legs into work position.




Observe all safety instructions and disengage the locking pins under the lift runners (if applicable).




LOWER the platform approx. 15 cm to disengage the stow locks.



OPEN the platform into horizontal work position.




Adjust the platform pitch to compensate for the slope of the ground [see §9.1 on page 46].




Unless unfolding automatically, deploy the guard rails and lock them in vertical position.

Deploy the cart-stops or retention ramp at the outboard platform edge.




Select between main external control box or auxiliary control to continue [see §9.2-9.3 on page 47-51]


Loading and unloading



LOWER the platform to the ground.




LIFT the platform off the ground. At the highest floor, continue to press LIFT until you hear the hydraulic system go in overpressure. Then, release the controls.




When riding on the platform, ALWAYS make sure you stand min. 25 cm away from the inboard platform edge. ALWAYS make sure your footing is solid. ALWAYS hold onto the guard rails. [see §7.5 from page 34 onwards].




NEVER pull the load from the vehicle onto the platform. ALWAYS push it out. Pulling the load from the vehicle can result in a fall from the platform and cause serious injury or death.




Before lifting or lowering loads, make sure the loads are secured on the platform surface. Deploy the platform cart stops (if so equipped), lower loads on a pallet jack down on the platform surface or immobilize the load via equivalent securement device.



Make sure you comply with load charts and instructions at all times




LOWER the platform to the ground, with respect for the load charts.




LIFT the platform off the ground, with respect for the load charts. At the highest floor, release the button when you hear the hydraulic system go in overpressure.

Closing up in travel position




Stow the cart-stops or retention ramp in their travel position.


Unless unfolding automatically, stow and secure the guard rails in their travel position.




LIFT or LOWER the platform to the correct height for closing it. Normally approx. 15 cm below the vehicle floor.



CLOSE the platform. Continue to press CLOSE until you hear the hydraulic system go in overpressure. Then release the controls.



LIFT the platform until the platform stow locks are engaged. Release the button when you hear the hydraulic system go in overpressure.



If applicable, engage the locking pins under the lift runners.



If so equipped, raise the mechanical or hydraulic stabilizing legs into travel position.



Switch off the electrical power to the tail lift (cabin switch or main battery disconnect switch in the external control box, or both if both are available). Close the cover of the control box.



At any time during the operation, release the activated button(s) to stop the platform from moving. Additionally, turning the main battery disconnect switch (if so equipped) counter-clockwise will switch off electrical power to the tail lift.


9.6 OPERATION OF THE INTERNAL COLUMN LIFT WITHOUT TILT CYLINDERS

- Internal lifts travel up and down between 2 or more vehicle floors inside the cargo body. They don't have tilt cylinders, their platform pitch cannot be altered during use.
- §9.2 through §9.3 explain how the functions LOWER - LIFT are executed via the various types of controls and this section explains in which sequence the DH-V* must be operated, and which steps must be followed.
- The images shown refer to instruction decal ref. EF0600.EN, usually affixed to the side of the vehicle body. See also section 10 on page 68.


Opening the platform



Consult the operation manual before getting started. Follow **ALL** safety and operation instructions.



Switch on the electrical power to the tail lift (cabin switch or main battery disconnect switch in the external control box, or both if both are available).




LIFT the platform approx. 5 cm to take the platform weight off the stow lock or pins.



Observe all safety instructions. Disengage the stow lock or pins underneath the platform.



If applicable (e.g. on curtain-sider vehicle), deploy the guard rails, and lock them in vertical position.




Select between main external control box or auxiliary control to continue [see §9.2-9.3 on page 47-51]




ALWAYS stand behind the platform while disengaging the stow locks or pins. NEVER stand or walk below a platform that is not secured by other means than its hydraulic cylinders and safety valves.

Deploy the cart-stops or retention ramp at the outboard platform edge.


Loading and unloading



LOWER the platform to the lowest vehicle floor.




LIFT the platform. At the highest floor, release the button when you hear the hydraulic system go in overpressure.




When riding on the platform, ALWAYS make sure you stand min. 25 cm away from the inboard platform edge. ALWAYS make sure your footing is solid. ALWAYS hold onto the guard rails. [see §7.5 from page 34 onwards].




When using a second external lift to load or unload to the vehicle ground, NEVER pull the load from the vehicle onto the platform. ALWAYS push it out. Pulling the load from the vehicle can result in a fall from the platform and cause serious injury or death.




Before lifting or lowering loads, make sure the loads are secured on the platform surface. Deploy the platform cart stops (if so equipped), lower loads on a pallet jack down on the platform surface or immobilize the load via equivalent securement device.



Make sure you comply with load charts and instructions at all times




LOWER the platform to the lowest vehicle floor, with respect for the load charts.




LIFT the platform, with respect for the load charts. At the highest floor, release the button when you hear the hydraulic system go in overpressure.


Closing up in travel position



LIFT the platform to approx. 5 cm above the height of the travel locks.



If applicable, stow the guard rails, and lock them in their travel position.



Engage the stow locks or pins underneath the platform. See notice.


Stow the cart-stops or retention ramp at the outboard platform edge.

NOTICE

While travelling, the platforms of interior lifts must be rested on and supported by travel locks or locking pins (different designs are possible):

1. To prevent damage to the cargo loaded on the lower deck in case of an accidental pressure loss in the hydraulic system causing the platform to creep down.
2. To avoid excess strain on the drive system of the lift (cables, chains pulleys, etc.), if the platform would travel around with heavy loads on it, in an unsupported way.

Negligence to do so, can cause premature wear or damage to the tail lift.



LOWER and rest the platform on the stow locks or pins, to reduce the strain on the drive system (cables, chains, pulleys, etc.) of the lift while travelling.



ALWAYS stand behind the platform while engaging the stow locks or pins. NEVER stand or walk below a platform that is not secured by other means than its hydraulic cylinders and safety valves.



Switch off the electrical power to the tail lift (cabin switch or main battery disconnect switch in the external control box, or both if both are available). Close the cover of the control box.



At any time during the operation, release the activated button(s) to stop the platform from moving. Additionally, turning the main battery disconnect switch (if so equipped) counter-clockwise will switch off electrical power to the tail lift.

9.7 OPERATION OF THE DH-VO.20.D4 REMOVAL LIFT

- The column lifts type DH-VO.20.D4 are equipped with telescopic lift runners, enabling the platform to reach to lifting heights above the vehicle roof level, up to max. 6 m above the ground (depending on vehicle dimensions).
- The removal execution OVU002.B has a number of extra standard features, to maximize the safety of the application:
 1. Hydraulic stabilizing legs to stabilize the vehicle and platform when working at extreme heights.
 2. Limitation of the lift capacity above roof level at 500 kg, to stabilize the vehicle and platform when working at extreme heights.

WARNING


- Lifting loads to and above vehicle roof level can destabilize the vehicle, the operator and the load on the platform.
- This can result in an accidental fall from the operator and / or the load from the platform, and can lead the severe personal injury or death to the operator or other bystanders.
- Therefore, the operator **MUST ALWAYS** deploy the hydraulic stabilising legs when going up beyond the vehicle roof level, or any lower height that causes instability due to the nature of the vehicle.
- If the platform movement feels unstable, **DO NOT** go any higher, try to stabilise the platform, and reduce the load on the platform in a safe way. Contact your superiors or DHOLLANDIA for further advice. See page 3 for contact info.

3. Detection on the stabilizing legs, to prevent the prevent the platform from being closed as long as the stabilizing legs are not fully retracted; and to prevent that the vehicle would drive-off with the stabilizing legs in the down position.
4. Guard rails on the 4 platform sides to prevent the operator on the platform from falling from extreme heights.

WARNING










- Falling from heights can cause serious bodily injury or death.
- To prevent injury or death by falling from the platform:
 - ALWAYS deploy the available guard rails at the 4 platform sides
 - ALWAYS make sure your footing in solid;
 - ALWAYS hold onto the guard rails;
 - ALWAYS maintain 3 points of contact.





- Only 1 type of external control box is available on this tail lift. Most functions work the same way as on the more conventional column lifts. Following differences exist to CLOSE or TILT UP:
 1. CLOSE the platform only works when the stabilizing legs are fully retracted in / up.
 2. The function HEIGHT DETECTION TO CLOSE assists you to find the correct height at which the platform can be closed safely (not too high to prevent hitting the platform against the roof, not too low to prevent the guard rails to crush into the cylinder beam).
 3. After CLOSING, the platform must be LIFTED further until stow locks are engaged.
 4. TILT UP, to adjust the pitch of the platform while the stabilizing legs are at the ground, requires a special combination of buttons.


- The external control box foresees following functions:




HEIGHT DETECTION to CLOSE




CLOSE when stabiliser legs are IN




TILT UP when stabiliser legs are OUT



Opening the platform




Consult the operation manual before getting started. Follow **ALL** safety and operation instructions.




Switch on the electrical power to the tail lift (cabin switch or main battery disconnect switch in the external control box, or both if both are available).




LOWER the hydraulic stabilizing legs into work position.




LOWER the platform approx. 15 cm to disengage the stow locks.



OPEN the platform into horizontal work position.




Adjust the platform pitch to compensate for the slope of the ground [see §9.1 on page 46].




Unless unfolding automatically, deploy ALL guard rails and lock them in vertical position.


Deploy the cart-stops or retention ramp at the outboard platform edge.




Select between main external control box or auxiliary control to continue. [see §9.2-9.3 on page 47-51]




Loading and unloading



LOWER the platform to the ground.




LIFT the platform off the ground. At the highest floor, release the button when you hear the hydraulic system go in overpressure.




When riding on the platform, ALWAYS make sure you stand min. 250 mm away from the inboard platform edge. ALWAYS make sure your footing is solid. ALWAYS hold onto the guard rails. [see §7.5 from page 34 onwards].



NEVER pull the load from the vehicle onto the platform. ALWAYS push it out. Pulling the load from the vehicle can result in a fall from the platform and cause serious injury or death.



Before lifting or lowering loads, make sure the loads are secured on the platform surface. Deploy the platform cart stops (if so equipped), lower loads on a pallet jack down on the platform surface or immobilize the load via equivalent securement device.



Make sure you comply with load charts and instructions at all times


LOWER the platform to the ground, with respect for the load charts. **Above roof level, limit the load to 500 kg max.**

LIFT the platform off the ground, with respect for the load charts. **Above roof level, limit the load to 500 kg max.** ALWAYS release the button when you hear the hydraulic system go in overpressure.

! WARNING


- Lifting very heavy loads above roof level can destabilize the vehicle, the operator and the load on the platform.
- This can result in an accidental fall from the operator and / or the load from the platform, and can lead to severe personal injury or death to the operator or other bystanders.
- Therefore, ALWAYS limit the load on the platform to max. 500 kg when lifting above roof level, or lowering from a height above roof level.
- If the platform feels unstable, DO NOT proceed, try to stabilise the platform, and reduce the load on the platform in a safe way prior to LIFTING or LOWERING further.

Closing up in travel position



Stow the cart-stops or retention ramp in their travel position.


Stow and secure the guard rails in their travel position.




LIFT or LOWER the platform to the correct height for closing it. Normally approx. 15 cm below the vehicle floor. Use the HEIGHT DETECTION TO CLOSE for your convenience.



Raise the hydraulic stabilizing legs into travel position. Release the button when you hear the hydraulic system go in overpressure.



CLOSE the platform. Continue to press CLOSE until you hear the hydraulic system go in overpressure. Then release the controls.



LIFT the platform until the platform stow locks are engaged. Release the button when you hear the hydraulic system go in overpressure.





Switch off the electrical power to the tail lift (cabin switch or main battery disconnect switch in the external control box, or both if both are available). Close the cover of the control box.



At any time during the operation, release the activated button(s) to stop the platform from moving. Additionally, turning the main battery disconnect switch (if so equipped) counter-clockwise will switch off electrical power to the tail lift.

9.8 THE USE OF STABILIZING LEGS

- Hydraulic stabilizing legs, operated via the main external control box, are available as an option on most tail lifts. Unless ordered otherwise, they are standard on the removal lifts type DH-VO.20.D4. They are available in capacities of 2.5 tons, 4 tons and 10 tons, and are therefore suitable for a wide range of commercial vans and trucks.
- The purpose of the stabilizing legs is to prevent the vehicle from tipping over, and to support the chassis of the vehicle during loading and unloading (e.g. vehicles with very long overhang, soft suspension, with relatively weak chassis, or in case of extreme lift capacities).




NOTICE


The use of stabilizing legs is mandatory on certain vehicles. Consult the operation manual and / or the Fitting and Body Building Instructions from the vehicle manufacturer.

- When using the stabilizing legs, the operator should observe following points:
 - Ensure that the stabilizing legs are positioned on solid even ground. In case of soft terrain (sand, gravel,...), solid support blocks must be used under the stabilizing legs. See image above right.
 - Use the stabilizing legs upon every loading / unloading activity.
 - Ensure the stabilizing legs are completely raised and stowed in travel position before moving the vehicle.
 - The stabilizing legs should be used to stabilize the vehicle only. They are not suitable to lift the vehicle.
 - The height of the stabilizing legs should be adjusted during loading and unloading, to adapt them to the variation in the vehicle suspension. Failure to properly adjust height of stabilizing legs increases the risk of serious injury or death to the operator and any bystanders.
- Operation:

Joystick control box (ref. OAE030.BT)



Arctic control box (OAE041.BP)




9.9 THE USE OF CART STOPS

WARNING

- If the load is not properly secured on the platform while lifting or lowering, it could shift position, destabilize the operator riding on the platform, and cause him / her to fall. Or the load could fall off the edge, and hit the operator or bystanders.
- Improperly secured cargo can put the operator and any bystanders at great risk of serious bodily injury and death.
- Therefore, all cargo must be properly secured on the platform, before lifting or lowering.


- Before lifting or lowering loads, ALWAYS apply all brakes or stops available to secure the load. Engage the wheel brakes of carts, trolleys or machinery (if available). When using pallet jacks, lower and rest the pallet or load onto the platform surface.
- DHOLLANDIA offers various cart-stop options, delivered to customer specification. Contact your regional DHOLLANDIA distributor for more information, prior to ordering your tail lift. See page 4 for contact info.
- The most popular cart-stop models are discussed below. Contact your regional DHOLLANDIA distributor for operational instructions on other models or models with different options, prior to operating the tail lift. See page 4 for contact info.



- Consult the DHOLLANDIA website to view operation videos on the various types of cart-stop systems (<http://www.dhollandia.com/US/en-us/101/#/cat/0>).

www.dhollandia.com → Videos → General → Roll-stop systems

OAP100.M = Manual cart-stops, operated by springs	
OPEN	Press the lever on the side of the cart-stop flap.
CLOSE	Step on the cart-stop flap. When driving a load from the ground onto the platform, the cart-stop will automatically close.




OAP100.A = Automatic cart-stops, operated by springs.

Cart-stop flap opens to 40°.

<p>OPEN MANUAL MODE</p>	<p>Kick the lever on the side of the cart-stop flap sideways from position 1 to position 2. The cart-stop will now function as a manual cart-stop OAP100.M.</p> <p>When stepping on the cart-stop flap, or when driving a load from the ground onto the platform, the cart-stop will automatically close.</p>
<p>OPEN AUTOMATICMODE</p>	<p>Kick the lever on the side of the cart-stop flap sideways + rearward, from position 1 to position 3. System will now function as automatic cart-stop.</p> <p>When stepping on the cart-stop flap, or when driving a load from the ground onto the platform, the flap automatically jumps back to the open position after releasing it, or when the load is passed over it.</p>
<p>CLOSE</p>	<p>Kick the lever into position 1. Step on the cart-stop flap.</p>



OAP100.A




OAP100.VA = Vertical cart-stops, operated by springs.

Cart-stop flap opens to 90°.

<p>OPEN MANUAL MODE</p>	<p>Kick the lever on the side of the cart-stop flap sideways from position 1 to position 2. The cart-stop will now function as a manual cart-stop OAP100.M.</p> <p>When stepping on the cart-stop flap, or when driving load from the ground onto the platform, the cart-stop will automatically close.</p>
<p>OPEN AUTOMATICMODE</p>	<p>Kick the lever on the side of the cart-stop flap sideways + rearward, from position 1 to position 3. System will now function as automatic cart-stop.</p> <p>When stepping on the cart-stop flap, or when driving a load from the ground onto the platform, the flap automatically jumps back to the open position after releasing it, or when the load is passed over it.</p>
<p>CLOSE</p>	<p>Kick the lever into position 1. Step on the cart-stop flap.</p>




OAP100.VA



OVP120.S.R / OVP120.A.R = Rear or outboard retention ramps in steel or aluminium



OVP120.S.S / OVP120.S.R = Side mounted retention ramps in steel or aluminium

OPEN	<p>Pull the rear side of the ramp towards you.</p> <p>Then raise the ramp in 90° vertical position and drop it down to lock.</p>
RAMP	<p>Raise the ramp to unlock.</p> <p>Swing it open towards the rear, and lay it open on the ground in ramp position</p>
CLOSE	<p>Raise the ramp.</p> <p>Swing it forward over 180° to lay it back onto the platform surface.</p> <p>The ramp will automatically lock when the platform is closed..</p>





OVP152 = Hydraulic retention ramp, electro-hydraulically operated

RAMP DOWN	Press RAMP DOWN on the main external control box or on the auxiliary controls. See §9.2 - 9.3.
RAMP UP	Press RAMP UP on the main external control box or on the auxiliary controls. See §9.2 - 9.3.



10 DECALS

- The following decals are supplied with each new tail lift, and should be affixed to the vehicle body during installation in the manner set forth in the adjacent drawings.
- NEVER remove or paint over any decal. Missing, worn or illegible warning decals must be immediately replaced. Get free replacement decals from DHOLLANDIA. Contact your regional DHOLLANDIA distributor. See page 4 for contact info.
- The operator should comply with all affixed safety and instructions decals. Be aware that the decals merely summarize the main points, and that the operator must know, understand, and comply with the full contents of the operation manual.
- Note: the decals marked as “EXAMPLE” can vary in function of the maximum rated capacity of the tail lift, or the chosen type of external control box.



1
See table

Type	Decal n°
External lift	EF0599.EN
Internal lift	EF0600.EN
DH-VO.20.D4 removal lift	EF0601.EN

OPERATION INSTRUCTIONS

OPEN PLATFORM

LOAD & UNLOAD

EXT. AUX.

CLOSE PLATFORM

DHOLLANDIA - EF0599.EN

OPERATION INSTRUCTIONS

OPEN PLATFORM

LOAD & UNLOAD

EXT. AUX.

CLOSE PLATFORM

DHOLLANDIA - EF0600.EN

OPERATION INSTRUCTIONS

OPEN PLATFORM

LOAD & UNLOAD

EXT. AUX.

CLOSE PLATFORM

DHOLLANDIA - EF0601.EN

2

EF0565.EN

⚠ WARNING - SAFETY INSTRUCTIONS

 Read and understand the user's manual, all instructions and warnings before use.

Carelessness or ignorance will put the operator and third parties at great risk of serious injury and death.

- Do not use liftgate unless you have been properly trained and instructed, you have read and you understand the full operating instructions.
- Wear appropriate working clothes, incl. footwear with steel toe caps and a good non-slip sole, and wear protective gloves.
- Ensure the vehicle is safely parked and braked before using the liftgate.
- Where applicable, refer to the site's specific risk assessment, and follow the local work & safety instructions.
- Always inspect the tail lift before using it. DO NOT use tail lift if there are signs of bad maintenance, subnormal wear or damage, or if the platform surface is slippery. DO NOT attempt to repair tail lift yourself, unless you have been trained and authorized to do so.
- Do not overload. Observe the maximum rated capacity and load charts.
- Do not stand behind or within reach of the platform.
- Make sure that platform area, including the area in which loads may fall from platform, is clear of obstacles and other people at all times.
- Make sure you can see and keep visual control over the whole working area of the liftgate, the platform and its load at all times.
- Beware of finger and toe traps at all times. When riding platform, stand at safe distance of minimum 10" from the inboard edge of the platform adjacent to the rear sill of the vehicle body.
- It is prohibited for anyone other than the operator to travel on the platform.
- Liftgate is intended for loading and unloading cargo only. Do not use liftgate for anything else but its intended use.
- Make sure platform is clearly visible from all approach directions (by means of flashing platform lights, platform flags, traffic cones, etc...) and that the working zone is sufficiently illuminated.

DHOLLANDIA EF0565.EN

6

EF0545

⚠ WARNING

Platform can crush. Keep feet clear from platform edge.

www.DHOLLANDIA.com

EF0545.EN

7

EF0563.EN

⚠ WARNING

Liftgate hazards can result in crushing or falling. Keep hands and feet clear of pinch points. If riding liftgate, make sure load is stable and footing is solid.

 Read and understand the user's manual, all instructions and warnings before use.

DHOLLANDIA • EF0563.EN

3

EF0585

EXAMPL

MAX. xxxx kg

Max. mm	1500 mm	1000 mm	0 mm
0 kg	yyyy kg	xxxx kg	xxxx kg

1701 5500

DHOLLANDIA xxxx kg

DHOLLANDIA EF0585

8

EF0562.EN

⚠ WARNING

Always stand clear of platform area.

DHOLLANDIA • EF0562.EN

4

EF0570 + capacity


MAX. 1500 kg

EF0570.01500

5

EF0564.EN

PLATFORM LOADING INSTRUCTIONS

Position load as close as possible to inboard platform edge.

Position load in middle line of platform. Avoid loading on 1 side only.

Operator should stand on side of load, well clear of inboard platform edge to avoid crushing feet.

Read and understand the user's manual, all instructions and warnings before use.

DHOLLANDIA EF0564.EN

⚠ WARNING

- Any person standing on the platform or inside the vehicle body, too close to the moving platform, risks being crushed between the moving platform and the vehicle floor, and can suffer serious bodily injury or death.
- To prevent injury or death by crushing or shearing:
 1. When standing inside the vehicle body, ALWAYS stand at a safe distance of min. 20" or 50 cm from the outboard edge of the vehicle floor.
 2. Before moving the platform, ALWAYS inspect the area UNDER and AROUND the platform. NEVER allow anybody step in or out of the vehicle body while the platform is in motion.
 3. When standing on the platform, ALWAYS stand at a safe distance of min. 10" or 25 cm from the inboard platform edge.

DHOLLANDIA • EF0594.EN

DHOLLANDIA

- Tail lift decals used and affixed in areas, other than the rear of the vehicle:

NOTICE

**LIFT GATE
SHUT-OFF
TO BE TURNED OFF
WHEN LIFT IS NOT
IN USE**

DHOLLANDIA • EF0814.EN.US


Cabin switch in driver's cabin to switch electrical power to tail lift on / off (if so equipped)

11 MEANING OF SAFETY AND WARNING SIGNS

WARNING signs	
	Overview and keep visual control over the working area of the tail lift at all times.
	General warning sign, used to alert the user to potential hazards. All messages that follow this sign shall be obeyed to avoid possible harm.
	Entrapment hazard. Keep hands, limbs, loose clothes and long hair away from moving parts.
	Crushing & shearing hazard. Keep hands away from moving parts.
	Crushing & shearing hazard. Keep feet away from moving parts.
	Slipping hazard.
	Tripping hazard.
	Hazard caused by tilting objects.
	Hazard of falling from heights.
PROHIBITION signs	
	General prohibition. DO NOT do!
	General prohibition. DO NOT do!
	DO NOT use machine by more than 1 operator!
	DO NOT step or stand here!

MANDATORY ACTION signs	
	Contact your regional DHOLLANDIA distributor.
	Consult the DHOLLANDIA website. Download from DHOLLANDIA website.
	Read the manual or instructions.
	Hold onto safety rail. Protect yourself from falling off the platform, or vehicle floor.
	Wear safety gloves.
	Wear safety-toe shoes.
	Wear appropriate work clothes, avoid loose-fitting clothes that might be trapped in the moving parts of the lift.
	Wear safety protection, eye protection and a safety hard hat.
	Use a safety shield.

Other frequently used signs

	Yes do this way. Correct work procedure.
	Yes do this way. Correct work procedure.
	No, DO NOT do this way. Incorrect work procedure.
	Position the load at the applicable centre of gravity or load centre. Follow the load instructions.
	Emergency stop. Will cause an immediate stop of the tail lift.
	Emergency exit. Provision (lever, valve,...) creating an emergency exit.
	Unlock. Disengage the mechanical locking system.
	Lock. Engage the mechanical locking system.
	Switch ON the electrical power.
	Switch ON the electrical power to the tail lift via the main battery disconnect switch and / or cabin switch.
	Switch OFF the electrical power.
	Switch OFF the electrical power to the tail lift via the main battery disconnect switch and / or cabin switch.
	This is an operation to be executed manually (as opposed to an electrical function controlled by means of one of the control units).

NOTICE

- Competent and regular preventative maintenance is essential to the operational reliability, and the safety of the operator and bystanders.
- All maintenance and repair work should be performed by authorized DHOLLANDIA service agents, and using only authorized OEM DHOLLANDIA replacement parts.
- Consult the separate MAINTENANCE AND REPAIR MANUAL for safety instructions, maintenance guidelines, and troubleshooting support.
- Lubricate the tail lift on a regular basis to maximize its durability and operational reliability. This is at least 3 times per year in a single shift operation; more frequently in case of very intensive use (multiple shift, 24h operation, etc.) or use in hostile environment conditions (frequent high pressure cleaning with strong detergents, etc.).